

Auditing e-data

Kim Hill, RQAP-GLP
NAICC Annual Meeting – San Antonio, TX
18 Jan 2024

Disclaimer

The following materials do not, and are not intended to, constitute legal advice. Always seek legal counsel as applicable. All materials presented are for general informational and educational purposes. They are not a legal interpretation of nor a statement of federal or state policy, regulations, or requirements, and they do not constitute an endorsement or recommendation by any federal or state agency. The views and personal opinions expressed by the presenter are his/her own and his/her appearance on the program does not necessarily reflect the views of BASF. BASF makes no representation or warranty with respect to the accuracy, applicability, fitness, or completeness of these materials. Under no circumstances shall BASF or its affiliates, officers, directors, employees, or representatives be liable for any direct, indirect, incidental, special, punitive, consequential, or any other damages that may result from the access of, use of, or inability to use, the materials, including without limitation, use of or reliance on information, misinformation, errors, defects, mistakes, omissions, or any other failure of performance.



Topics

- Validation
- Auditing Raw Data
 - Notebooks
 - ► Sample Tracking
 - ► Temperature Data
 - ► Reagents/Solutions
 - ► Equipment Maintenance
 - ► Analytical Data
- Spreadsheets



Validation

- Any electronic system must be validated, including how it will be used at the facility.
 - ► Simple or complex system? Fully electronic process or hybrid?
 - Interfaces with other systems or programs?
 - Data flow
 - Audit Trail
 - Turned on; not able to be turned off
 - Reporting feature
 - Periodic review
- Quality Assurance (QA) involvement in the validation project
 - ► Helpful to understand how system designed, how it works



Auditing in General

- When to audit data?
 - ► In-progress inspections
 - Data audits
 - ► Final/Phase report audits
 - ► Facility inspections
- Start with:
 - Protocol/changes
 - Methods
 - ► Standard Operating Procedures (SOPs)
- QA training and system access



Auditing e-Notebooks

- Check any notes/files that may be included in the e-notebook.
- Check completeness of the notebook; no blanks.
- Confirm protocol requirements met and documented. Deviations should be documented.
- Confirm method and SOP requirements met and documented. Deviations should be documented.
- Check the audit trail.
 - ► Confirm direct entry
 - If not, is there an indication that the data was transcribed?
 - Check for the original raw data; confirm e-notebook matches the original raw data.



Auditing Sample Tracking

- Sample logs used for tracking:
 - ▶ Receipt
 - ► Storage location
 - ► Preparation for analysis
 - Shipping
 - Disposal



Auditing Temperature Data

- Dataloggers
 - ▶ Data downloaded per SOP?
 - ► Electronic records are kept?
 - Data summary reflects original data?
- Temperature Monitoring System
 - Review data for equipment used during study conduct.
 - Storage per protocol?
- Typically, temperature records are considered facility data; however, it supports study conduct and must be retained.
 - ► For storage stability studies, make sure to include temperature data in the study file for the duration of the study, for each storage unit used.

Auditing Equipment Logs

- Check that maintenance is being performed per the SOP.
- Maintenance activities should be entered on the day they were performed.
 - ▶ Maintenance performed by an external party may not have been entered on the same day.
 - In this case, check the maintenance date entered is supported by the documentation received.
 - This documentation must be maintained.
- Non-routine maintenance entries should include all the required information per the GLPs.
- For maintenance captured in an electronic system, check the audit trail.



Auditing Reagent & Solution Records

Reagents

- Check correct expiration date assigned.
- Check non-expired reagents are used.

Solutions

- Check correct components used.
- Check correct amount used.
- Check components are not expired.
- Check correct expiration date assigned.



Auditing Analytical Data

- Sample and standard preparation
- Instrument set-up
- Acceptance criteria
- Robots
- Audit trail



Auditing Spreadsheets

- Software that writes data to a LIMS or spreadsheet.
 - ► The electronic data is the original data.
 - ► The software and process need to be validated.
 - ► If data is written to a spreadsheet:
 - The spreadsheet must be printed, initialed/dated by the person performing the activity.
 - Check that the information on the printout matches that of the electronic file.
 - The file save date should match the date of the activity and date on the printout.
- A spreadsheet is often used to perform calculations on the data generated.
 - ► Validation is helpful, to avoid having to do full QC/QA on the file.



